

# E100M

## Manual Waterborne Spray Gun Cleaner



Check out our  
Brief  
Training Videos at  
[www.beccainc.com](http://www.beccainc.com)



- **POWERCLEAN** •  
PROTECTS AIR PASSAGEWAYS
- **OVERSIZED STAINLESS WORK BASIN** •  
SPACIOUS WORK AREA
- **PULSATING FLUID POWER CLEANING** •  
FLUSHES AWAY CONTAMINATION

# E100M

## Manual Waterborne Spray Gun Cleaner

The New BECCA E100M Spray Gun Cleaner is designed to meet the challenges of getting waterborne spray guns clean quickly...

- Cleans all of the fluid passageways
- Protects air passageways to prevent contamination and corrosion
- Cleaning solution can be recycled and reused many times

### STANDARD UNIT FEATURES:

- STAINLESS STEEL BASIN w/ COVER - Oversized work Area
- POWERPISTOL™ - Quick & Powerful Spray Gun Cleaning
- POWERCLEAN™ - Compressed Air Connection Protecting Air Passageways
- PULSATING FLUID - Powerful Cleaning Efficiency
- SPLASH PAD - In Basin to Reduce Splash - Self Cleaning
- FLOW BRUSH/SPIGOT - Combined to Serve both Functions
- AIR PISTOL - Quick Drying Interior & Exterior Residual Fluid
- FOOT PEDAL - Hands-Free Fluid/Pump Control
- COMPOSITE QD'S - High Flow Corrosion Resistant
- GREEN POWDER COATED FINISH - Long Maintenance Life
- 5 GALLON CONTAINER w/ LID - Fluid Reservoir
- INPUT AIR FILTER/REGULATOR - Proper System Air Control
- CLARIFIER RECYCLING SYSTEM w/ 3 Containers, Dual Filters & Air Bubbler
- NESHAP COMPLIANT - Meets NESHAP Requirements



### Product Specifications:

Dimensions:

Overall:

44"H x 26"W x 23"L  
118 mm x 660mm x 584 mm

Working: (Stainless Basin)

9"D x 21"W x 19"L  
228 mm x 533mm x 483 mm

Weight: 110 lbs (50 kg)

Shipping: Via Freight

### OPTIONAL UPGRADES:

- ENVIRO™ CARTRIDGE FILTRATION w/ 75 Micron Filter
- HEAT SYSTEMS - Elevates Temperature to reduce cleaning time
- SPLASH CONE - Enclosure to contain Spray Gun Flush Splash



**POWERPISTOL™ - Pulsating Fluid...**  
Powerful Cleaning for the Fluid Passageways



**OVERSIZED STAINLESS STEEL BASIN** ..... A Spacious Work Area for Easy Use



**POWERCLEAN™** .... Supply's Compressed Air to the Spray Gun During the Cleaning Process, Protecting the Air Passageways



**BECCA®**

2010 Cobb International Blvd, Suite H Kennesaw, GA 30152  
Phone 800.655.5649 Fax 800.655.5684 Internet: [www.beccainc.com](http://www.beccainc.com)