



E800A

Deluxe Automatic/Manual Waterborne Spray Gun Cleaning Workstation

- **POWERCLEAN** •
Protects Air Passageways
- **AUTOMATIC WASH BASIN** •
Hands-Free Operation
- **PULSATING FLUID POWER CLEANING** •
Flushes Away Contamination

The BECCA E800A Automatic Spray Gun Cleaner Workstation is designed to meet the challenges of getting waterborne spray guns clean quickly...

- Cleans all of the fluid passageways
- Protects air passageways to prevent contamination and corrosion
- Cleaning solution can be recycled and reused many times

Check out our brief Training Videos at
www.beccainc.com



E800A

Deluxe Automatic/Manual

Waterborne Spray Gun Cleaning Workstation



Product Specifications:

Dimensions:

Overall:

57" H x 26" W x 26" D
1447 mm x 660 mm x 660 mm

Working: (Stainless Steel Basin)

14" H x 20" W x 12" D
356 mm x 508 mm x 305 mm

Weight: 270 lbs (123kg)

Shipping: Via Freight

STANDARD UNIT FEATURES:

- Water Wave™ Sample** – Cleaning Solution with Micro Film Technology for Waterborne Paints
- Flocer™ Sample** – Flocculation Powder for Clarification Recycling
- Stainless Steel Basin w/ Cover** – Painter Friendly
- Automatic Hands-Free Cycle** – Reduces Operator's Time
- Powerpistol™** – Quick & powerful Spray Gun Cleaning
- Powerclean™** – Compressed Air Connection Protecting Air Passageways
- Pulsating Fluid** – Powerful Cleaning Efficiency
- Used/Clean Fluid Control** – Superior Cleaning and 50% Solvent Savings
- Flow Brush** – Improved Cleaning of dried material
- Air Pistol** – Quick Drying Interior & Exterior of Residual Fluid
- Ultra Light™ QD's** – High Flow light weight Corrosion Resistant
- 5 Gallon Container w/ Lid** – Fluid Reservoir
- Green Powder Coated Finish** – Long Maintenance Life
- Input Air Filter/Regulator** – Proper System Air Control
- Clarifier Recycling System w/ Air Bubbler** – 3 Containers and Dual Filter System
- NESHAP and NFPA 33 Compliant** – Meets Requirements

Optional Upgrades:

- Heat Systems** - Elevates Temperature to reduce cleaning time
- Cover Door** - Required in some Jurisdictions
- Dual PowerClean Kit** - Second Spray Gun Connection in the Wash Basin
- Enviro™ Cartridge Filtration** - Less Maintenance & Improved Productivity with a Two Stage Filtration System (75 & 25 Micron Filters)



POWERPISTOL™ - Pulsating Fluid. Powerful cleaning for the Fluid Passageways



STAINLESS STEEL AUTOMATIC WASH BASIN - Maximize Operator



Manual



Automatic

POWERCLEAN™ - Supply's compressed air to the Spray Gun during the cleaning process, protecting the air passageways.